WINTERIZATION CHECKLIST

Below is the list I use when I park/store the RV during the winter - anytime the temperature will dip below 30 for any prolonged amount of time.

Most up-to-date version with links here: http://www.winnieview.com/tips.html#winterizing

PREPARE FOR WINTER STORAGE

- □ Top off the Diesel tank with winterized blend
- □ If temperature may drop below 12 degrees Fahrenheit, make sure you DEF tank is only half full. Do NOT add any additives when storing or when coming out of storage
- Top off windshield washer fluid with winterized blend
- □ Prop refrigerator doors open with the plastic clips that are under each of the door's handles
- □ If the RV will not remain plugged into power, disconnect the house batteries and hook up trickle charger to chassis battery
- □ Remove all bottled liquids and canned foods from RV
- □ Disconnect the water
- Open the primary fresh water tank drain valve inside the water bay
- Open the two plumbing drain valves (hot and cold) inside the water bay
- □ Wait for all water to stop dripping from underneath RV
- □ Close the primary fresh water tank drain valve inside the water bay
- □ Turn ON water pump until no water comes out of two plumbing drain valves
- □ Turn OFF water pump
- □ Close the two plumbing drain valves
- □ Drain the hot water tank open the outside door, open the pressure relief valve, and remove the small white plug STAND BACK! Hot water will flow!
- □ Remove the water filter under the kitchen sink and apply bypass plug
- □ Turn OFF all faucets and shower
- □ Replace the hot water tank drain plug and close the pressure relief valve
- □ Turn OFF the primary fresh water tank drain valve inside the water bay
- □ Turn OFF the two plumbing drain valves (hot and cold) inside the water bay
- Hook up compressor to your main water line using this attachment, set the compressor pressure to 50 PSI or less, and turn on compressor
- Open the kitchen sink HOT water and run until only air comes out. Close
- Open the kitchen sink COLD water and run until only air comes out. Close
- Do the same HOT then COLD in the bathroom sink
- □ Flush toilet until only air comes out
- □ Run toilet sprayer until only air comes out
- □ Open the shower HOT water and run until only air comes out. Close
- □ Open the shower COLD water and run until only air comes out. Close
- Open the outside shower HOT water and run until only air comes out. Close



winnieView - http://www.winnieview.com

- □ Open the outside shower COLD water and run until only air comes out. Close
- Open the primary fresh water tank drain valve inside the water bay and switch the water fill lever to "tank fill" for about 10 seconds. Close and switch lever back

Continued...

- Open the HOT plumbing drain valve inside water bay until air comes out. Close
- □ Open the COLD plumbing drain valve inside water bay until air comes out. Close
- □ Repeat the above steps for kitchen sink, bathroom sink, toilet, shower, and outside shower
- □ Turn off the compressor and disconnect the flush attachment from the fill hose and, if you have a permanently mounted fill hose, cap the fill hose
- □ Add about two cups each of RV anti-freeze (the pink stuff) (Walmart also carries seasonally) to the kitchen sink drains (2), bathroom sink drain, and shower drain. Add about 4 cups to the toilet and flush, then add 2 cups and leave in toilet bowl

